

DAY MARKER

For Elevated Lights



Day Marker

for Elevated Lights
Series EL 224/225

Features

- suitable for use with all runway and taxiway edge lights
- simple installation and replacement
- overlays fitting base plate
- clamp mounted directly below the light at the pedestal
- two-part Day Marker is made from a weatherproof synthetic material
- white top part has laminated segments of a red colored foil to give a warning appearance

General

The Day Marker is simply attached to the elevated edge light fittings where its high visibility creates enhanced awareness of the presence of the fitting. The highly reflective marker facilitates use on the runway as well as the apron and taxiway areas in both day time and night time applications.

Dimensions/Weights

Article	Weight
Top part, material aluminium	0,277 kg
Lower part, material synthetic	0,273 kg

Dimensions	
Outer diameter	306 mm
Inner diameter	125 mm
Height	95 mm

Options

- yellow top part
- yellow/red top part

Subject to change